TECH SHEET FUS32BELV

Lightly sand to enhance bond. Surface should be prepared as for any final finish.

- 1. Clean surface with water and soap.
- 2. Clean fully cured paint surfaces with Wax and Grease Remover. For plastic surfaces clean with Plastic Parts Cleaner. For newly painted surfaces use Final Wipe.
- 3. Shake thoroughly before using
- . 4. Using a siphon gun at 40-80 psi, adjust air pressure and spraying distance to match factory texture.
- 5. Under normal conditions, allow 1-1/2 to 2 hours drying time. Make sure coating is fully cured before top coating.
- 6. When top coating, apply a first thin coat. Allow 5 minutes flash time. Follow with a full wet coat.

CAUTION: It is important to test the compatibility of this product with your paint system. This product is not recommended for use in temperatures below 16°C (60°F). The use below these temperatures will affect dry times and performance.