

## **TECH SHEET FUS13B**

### **European Texture Rubberized Gravlguard**

1. Shake can for 1 minute after mixing ball moves freely.  
Note: Insufficient mixing may cause permanent plugging of the spray head.
2. Prepare surfaces as for paint. Remove silicone, wax, grease and dirt with Wax and Grease Remover prior to sanding.

3. Bare metal should be primed. Use Aerosol Self Etching Primer or Epoxy Primer

4. Spray can approximately 25 to 30 cm (10 to 12 inches) from surface. Distance will determine texture.

5. To assure that entire contents will be dispensed, always have the dot on can rim facing towards surface to be sprayed.

6. Can be painted in 1 hour under normal shop conditions. Low temperatures 16°C (60°F) or high humid conditions 21°C (70°F) or more allow 30 minutes more of dry time.

7. When finished turn can upside down and spray about 3 seconds to clean out spray head. Save spray heads in a small can of paint thinner as spares.