

## **FUS32BLV TECH SHEET**

Lightly sand to enhance bond. Surface should be prepared as for any final finish.

1. Clean surface with water and soap.
2. Clean fully cured paint surfaces with Wax and Grease Remover. For plastic surfaces clean with Plastic Parts Cleaner. For newly painted surfaces use Final Wipe.
3. Shake thoroughly before using
- . 4. Using a siphon gun at 40-80 psi, adjust air pressure and spraying distance to match factory texture.
5. Under normal conditions, allow 1-1/2 to 2 hours drying time. Make sure coating is fully cured before top coating.
6. When top coating, apply a first thin coat. Allow 5 minutes flash time. Follow with a full wet coat.

**CAUTION:** It is important to test the compatibility of this product with your paint system. This product is not recommended for use in temperatures below 16°C (60°F). The use below these temperatures will affect dry times and performance.