

TECH SHEET

FUS100 Premium Finishing Putty

SURFACE PREPARATION:

1. Surface must be free of rust, wax, silicone, grease, dirt, and other contaminants.
2. Clean metal surfaces with Wax and Grease Remover. Wipe dry while the surface is still wet.
3. Sand substrate using 120-240 grit abrasive depending on use. Fully sand aged topcoats and ensure new primer applications are fully cured before applying.
4. Use clean dry air and blow surface free of dirt.

MIXING DIRECTIONS: Mixing Ratio: Mix 2% of cream hardener to FUS100. Knead cream hardener tube before using. Using a non contaminated mixing board, mix thoroughly until mixture is color consistent.

DIRECTIONS FOR USE:

1. Mix the desired quantity of product.
2. Apply filler with a clean spreader. Fill should not exceed 3 mm (1/8") in depth.
3. Allow to cure thoroughly.
4. Break with 120 grit sandpaper and finish with 180-240 grit.
5. Topcoat with a premium quality primer.

CAUTION: Do not return catalyzed material to can. To avoid contamination, keep cap closed after use.