



## **TECH SHEET R500L-R501L-R502L**

### **Mixture by volume:**

1 to 2% of catalyst / hardener per 100 parts of resin;

Mix the resin with its catalyst well for about 30 seconds. Do not apply in the sun;

### **Cleaning solvent:**

Acetone.

### **Handling Precautions:**

The usual precautions for handling polyester resins and polyester hardeners apply as well as adequate ventilation.