



TECH SHEET R1720C-R1721C

APPROVED SUBSTRATES: ♣ Steel ♣ Fiberglass ♣ Galvanized Steel ♣ Most Rigid to Semi-Rigid Plastics

PREPARATION:

- Clean and degrease the entire panel to be repaired with soap and water, followed by a mild cleaning solvent. Thoroughly dry the surface before repairing.
- Use 80-180 grit to remove or scuff the paint and featheredge.

MIXING: • Place the desired amount of material on a clean, non-fibrous surface. Knead the cream hardener before use.

- Measure hardener 2% by weight (add a ribbon of cream hardener from edge to edge across the center of a 4" (10 cm) diameter puddle. Puddles larger than 4" in diameter will require additional hardener.
- Mix thoroughly until uniform color is achieved.
- Approximate setting time is 5 - 6 minutes @ 72°F (22°C)

APPLICATION:

- Spread a thin layer of mixed material over surface using firm pressure.
- Apply additional layers to build material slightly higher than the surface to allow for sanding to desired contour

NOTE: Do not apply over new or uncured coatings. Avoid thick heavy applications.

FINISH:

- Sand to contour with 180 grit sandpaper.
- Final sand with 180 grit followed by 220-320 grit if desired.

TOPCOAT:

- Apply 2K polyester, 2K urethane, 2K epoxy, or 1K primer to manufacturer's recommendations